

# Word Prediction in Scanning

This exercise will teach you how the Lightwriter's Word Prediction operates. This will help to speed up your typing. Try it and see.

word predictions are shown on the left side of the screen:



The Word Prediction can be set to predict after 1, 2 or 3 letters. This is changed in the Lightwriter's setups.

## 1. Enter the first letter of the word

The Lightwriter predicts what you might want to say. It shows the four most common words beginning with the letter(s) you have entered on the left side of the screen.

## 2. If the word you were thinking of is shown: select the row it is in, then select the predicted word.

This will enter the whole word, followed by a space.

## 3. If word is not shown, enter the next letter in the word.

Notice that the four word predictions change.

## 4. If the word you were thinking of is now shown: select it, otherwise continue adding additional letters until the word you want is shown.

## 5. If the Word Prediction stops showing any more words: type the rest of the word, followed by **Space**, as normal.

---