








Setting up a Plug-in Scan Module

This activity steps through changing Lightwriter setups for a Plug-in Scan Module.
This activity takes about 1 minute.



1. Press 
 2. Press  then  to enter the setup menu.
 3. Press the  key repeatedly to find **Port 1** setup.
 4. Change setting to **Scanner** using  key
 5. Press the  key once or twice more to find the **Predict After** setup.
 6. Change setting to **Off / 1 / 2 / 3** as required using  key
 7. Press 
 8. Plug the Plug-in Scan Module into **Port 1** (right hand side of Lightwriter)
 9. Plug a switch into **Switch 1**, (and a 2nd switch into **Switch 2**, if using 2-switch scanning) (these are labelled **Scan 1** and **Scan 2** on older Lightwriters).
 10. The Lightwriter and Scan Module are now ready to operate.
-