

Setting up Scanning Lightwriters

This activity steps through changing Lightwriter setups for scanning.
This activity takes about 2 minutes.



SL85 only:

1. Plug the Plug-in Keyboard into **Port 1** (right hand side of Lightwriter)
2. Press the **Speed** button then the **Delete** button on the front of the SL85.
3. Screen shows **Port1: keyboard** The Plug-in Keyboard is now active.

All models

- 1 Press **On/C**
 - 2 Press **Mem** then **↶** to enter the setup menu.
 - 3 Press the **P** key once or twice more to find **Predict After:** setup.
 - 4 Change **Word Prediction** setting to **Off / 1 / 2 / 3** as required using **+/-** key.
 - 5 Press the **S** key repeatedly to find **Scan Speed:** setup.
 - 6 Change the **Scan Speed** setting using **+/-** key.
 - 7 Press the **A** key repeatedly to find **Auditory Scan:** setup.
 - 8 Change the **Auditory Scan** setting to **Beep, Speak, or Off** using **+/-** key.
 - 9 *if 2-switch step scanning is required: Press the **S** key repeatedly to find **Scan (1):** setup.*
 - 10 *Change the **Scan (1):** setting from **Auto** to **Manual** using **+/-** key.*
 - 11 (Change any other setups as required)
 - 12 Press **Off**
 - 13 If using SL85: remove the Plug-in Keyboard if it's no longer being used.
 - 14 If using a Plug-in Scan Module, plug the Scan Module into **Port 1** (right hand side of Lightwriter) The Lightwriter and Scan Module are now ready to operate.
 - 15 Plug a switch into **Scan1**, (and a 2nd switch into **Scan2**, if using 2-switch scanning)
 - 16 Press the Scan Switch (or Scan Switch1 if using 2-switch scanning), and the Lightwriter will wake up and scanning will start automatically.
-

